



DEPARTAMENTO “SEGURIDAD OPERACIONAL”
SUBDEPARTAMENTO “LICENCIAS”
SECCIÓN EVALUACIONES

“BEEHCRAFT SUPER KING AIR B200/B200C”

A.- Limitaciones de Operación

1.- Limitaciones (KIAS)	
Va	181
Vb	170
Vmo	259
Mmo (Mach)	0.52
Vfe Approach 40%	200
Vfe Full Down 100%	157
Vmca (Hartzell)	86
Vs	99
Vso	75
Vx	100
Vy	125
Vyse	121
V ₁	95
Vapp	103
Max Cross Wind	25

2.- Combustible (U.S. GAL)	
Tipo a Utilizar	JET A-1
Capacidad Total	544

3.- Pesos (LBS)	
Máximo TAKE-OFF	12500
Máximo LANDING	12500
MAX ZFW	11000

4.- Starter Limitations					
40	SEC	ON	60 SEC	OFF	60 SEC
40	SEC	ON	60 SEC	OFF	60 SEC
40	SEC	ON	30 MIN	OFF	30 MIN

B.- Emergencies Procedures

1-. ENGINE FAILURE IN FLIGHT OR FIRE IN FLIGHT

a.- Affected engine:

Condition Lever

FUEL CUTOFF

Prop Lever

FEATHER

Firewall Shutoff Valve

CLOSE

Fire Extinguisher (if installed) (if fire warning persists)

ACTUATE

2-. ENGINE FIRE ON GROUND

a.- Affected engine:

Condition Lever

FUEL CUTOFF

Firewall Shutoff Valve

CLOSE

Ignition and Engine Start

STARTER ONLY

b.- If Fire Warning Persists:

Fire Extinguisher (if installed)

ACTUATE

3-. ENGINE SHUTDOWN ON THE GROUND

Condition Levers

FUEL CUTOFF

Prop Levers

FEATHER

Firewall Shutoff Valves

CLOSE

Master Switch (gang bar)

OFF

4-. ENGINE FAILURE DURING TAKEOFF (AT OR BELOW V_1) TAKEOFF ABORTED

Power levers	GROUND FINE
Brakes	AS REQUIRED TO ACHIEVE STOPPING DISTANCE
Operative engine	MAXIMUM REVERSE

a.- If insufficient runway remains for stopping:

Condition Levers	FUEL CUTOFF
Firewall Shutoff Valves	CLOSE
Master switch	OFF (Gang bar down)

5-. ENGINE FAILURE DURING TAKEOFF (AT OR ABOVE V_1) TAKEOFF CONTINUED

Power	MAXIMUM ALLOWABLE
Airspeed	MAINTAIN (take-off speed or above)
Landing Gear	UP
Prop Lever (inoperative engine)	FEATHER (or verify FEATHERED if autofeather is installed)
Airspeed (After obstacle clearance altitude is reached)	Vy _{se}

6-. ENGINE FAILURE IN FLIGHT BELOW AIR MINIMUM CONTROL SPEED (V_{MCA})

Power	REDUCE AS REQUIRED TO MAINTAIN CONTROL
Nose	LOWER TO ACCELERATE ABOVE V_{MCA}

7-. ENGINE FLAMEOUT (2ND ENGINE)

Power Lever	IDLE
Prop Lever	DO NOT FEATHER
Condition Lever	FUEL CUTOFF
Conduct Air Start Procedures in ABNORMAL PROCEDURES	

8-. FUEL PRESSURE LOW (L or R FUEL PRESS ANNUNCIATOR)

Standby Pump (failed side)	ON
----------------------------	----

9-. ELECTRICAL SMOKE OR FIRE

Oxygen System Ready	CONFIRM ON
Crew (Diluter Demand Masks)	DON MASKS
Mask Selector Switch	EMERGENCY Position
Mic Selector	OXYGEN MASK
Audio Speaker	ON

10-. ENVIRONMENTAL SYSTEM SMOKE OR FUMES

Oxygen System Ready	CONFIRM ON
Crew (Diluter Demand Masks)	DON MASKS
Mask Selector Switch	EMERGENCY Position
Mic Selector	OXYGEN MASK
Audio Speaker	ON

11-. CABIN OR CARGO DOOR UNLOCKED (DOOR UNLOCKED Annunciator)

All Occupants

SEATED WITH SEAT BELTS
SECURELY FASTENED

12-. EMERGENCY DESCENT

Oxygen

CREW REQUIRED

(Passengers as required)

Oxygen System Ready

CONFIRM ON

Crew (Diluter Demand Masks)

DON MASKS

Mic Selector

OXYGEN MASK

Audio Speaker

ON

Passenger Manual Drop Out

PULL ON

Passengers

PULL LANYARD PIN, DON
MASK

Power Levers

IDLE

Prop Levers

FULL FORWARD

Flaps

APPROACH

Landing Gear

DOWN

Airspeed

181 KNOTS MAXIMUM

13-. GLIDE

Landing Gear

UP

Flaps

UP

Props

FEATHERED

Airspeed

135 KNOTS

14-. INVERTER INOPERATIVE (INVERTER Annunciator)

Select

THE OTHER INVERTER.

15-. DUAL GENERATOR FAILURE

Generators

RESET, THEN ON

a.- If Either Generator Will Reset:

Operating Generator Loadmeter

DO NOT EXCEED 100%
(88% above 31,000 feet)

16-. UNSCHEDULED ELECTRIC ELEVATOR TRIM

Airplane Attitude

MAINTAIN (Using elevator control)

Control Wheel Disconnect Switch

FULLY DEPRESS

2nd level, ELECT TRIM OFF Annunciator

ILLUMINATED

17-. UNSCHEDULED RUDDER BOOST ACTIVATION

Directional control

MAINTAIN USING RUDDER
PEDALS

Rudder boost

OFF

18-. USE OF OXYGEN

Cabin Pressure Altitude	TUC
Oxygen System Ready	CONFIRM ON
Crew (Diluter Demand Masks)	DON MASKS
Mic Selector	OXYGEN MASK
Audio Speaker	ON
Passenger Manual Drop Out	PULL ON
Passengers	PULL LANYARD PIN, DON MASK

19-. PRESSURIZATION LOSS (ALT WARN Annunciator)

Oxygen	
Oxygen System Ready	CONFIRM ON
Crew (Diluter Demand Masks)	DON MASKS
Mic Selector	OXYGEN MASK
Audio Speaker	ON
Passenger Manual Drop Out	PULL ON
Passengers	PULL LANYARD PIN, DON MASK
Descend	AS REQUIRED

20-. AUTO - DEPLOYMENT OXYGEN SYSTEM FAILURE (ALT WARN Annunciator Illuminated y PASS OXY ON Annunciator Not Illuminated)

Passenger Manual Drop Out	PULL ON
---------------------------	---------

21-. HIGH DIFFERENTIAL PRESSURE (Cabin Differential Pressure Exceeds 6.6 psi)

Bleed Air Valves	ENVIRONMENT OFF
Oxygen (Crew and Passengers)	AS REQUIRED
Descend	AS REQUIRED

22-. BLEED AIR LINE FAILURE (L or R BL AIR FAIL Annunciator)

Bleed Air Valve (Affected Engine)	INST & ENVIRONMENT OFF
	[L BL AIR OFF] or [R BL AIR OFF]-ILLUMINATED

23-. SPINS

Control Column	FULL FORWARD
	AILERONS NEUTRAL
Full Rudder	OPPOSITE THE DIRECTION OF SPIN
Power Levers	IDLE
Rudder	NEUTRALIZE WHEN ROTATION STOPS
Execute a Smooth Pullout	