

<b>Nombre del alumno:</b>			
<b>Fecha</b>	<b>Lección</b>	<b>Aprobado</b>	<b>Reprobado</b>
<b>Nombre y Firma del Instructor que revisó</b>		<b>Firma del alumno</b>	

## A.- LIMITACIONES DE OPERACIÓN

### 1.- Limitaciones (Velocidades)

	<b>KIAS</b>
<b>V<sub>A</sub></b>	2.550 Pounds <b>105</b>
	2.200 Pounds <b>98</b>
	1.900 Pounds <b>90</b>
<b>V<sub>NE</sub></b>	<b>163</b>
<b>V<sub>NO</sub></b>	<b>129</b>
<b>V<sub>FE</sub></b>	Flaps 10° <b>110</b>
	Flaps 10° to Full <b>85</b>
<b>V<sub>s</sub></b>	<b>48</b>
<b>V<sub>so</sub></b>	<b>40</b>
<b>V<sub>x</sub> (Sea Level)</b>	<b>62</b>
<b>V<sub>y</sub> (Sea Level)</b>	<b>74</b>
<b>V<sub>R</sub></b>	<b>55</b>
<b>V apch (Flaps Full)</b>	<b>60 - 70</b>
<b>V normal (Flaps UP)</b>	<b>65 - 75</b>
<b>V planeo</b>	<b>68</b>
Máxima velocidad recomendada para ingresar en aire turbulento	
	2.550 Pounds <b>105</b>
	2.200 Pounds <b>98</b>
	1.900 Pounds <b>90</b>
Maximum Demonstrated Crosswind Velocity	
<b>Take Off, Flaps Up</b>	<b>20</b>
<b>Take Off, Flaps 10°</b>	<b>20</b>
<b>Landing, Flaps 10°</b>	<b>20</b>
<b>Landing, Flaps FULL</b>	<b>15</b>

### 3.- Combustible (U.S. GAL)

<b>Tipo a Utilizar</b>	<b>100LL Azul</b>
<b>Capacidad Total</b>	<b>56</b>
<b>Combustible Usable</b>	<b>53</b>

### 2.- Motor (Potencia Máxima Continua)

<b>Limitaciones Operativas de Motor</b>	
<b>Razón HP o BHP</b>	<b>180 BHP</b>
<b>Máximas RPM</b>	<b>2700</b>
<b>RPM estáticas</b>	
<b>Mínimas</b>	<b>2300</b>
<b>Máximas</b>	<b>2400</b>
<b>Temperatura de aceite (°F)</b>	
<b>Mínima</b>	<b>100</b>
<b>Máxima</b>	<b>245</b>
<b>Presión de Aceite (PSI)</b>	
<b>Mínima</b>	<b>20</b>
<b>Máxima</b>	<b>115</b>

### 4.- Aceite (US. Qts.)

<b>Capacidad Total</b>	<b>9</b>
<b>Utilizable</b>	<b>8</b>
<b>Mínimo para operar</b>	<b>5</b>

**5.- Pesos (LBS)**

<b>Máximo TAKE-OFF</b>	<b>2550</b>
<b>Máximo Equipaje</b>	<b>120</b>

**6.- Limites de maniobra (Cat. Normal)**

MANIOBRA	KIAS
<b>Chandela</b>	<b>105</b>
<b>Ocho Flojo</b>	<b>105</b>
<b>Escarpados</b>	<b>95</b>
<b>Stalls (except whip stalls)</b>	<b>Slow deceleration</b>
<b>El uso brusco de los controles está prohibido sobre:</b>	<b>105</b>

**7.- Limites de maniobra (Cat. Utilitaria)**

MANIOBRA	KIAS
<b>Chandela</b>	<b>105</b>
<b>Ocho Flojo</b>	<b>105</b>
<b>Escarpados</b>	<b>95</b>
<b>Spins</b>	<b>Slow deceleration</b>
<b>Stalls (except whip stalls)</b>	<b>Slow deceleration</b>

**B.- EMERGENCY PROCEDURES****- ENGINE FAILURE DURING TAKEOFF ROLL**

- 1.- Throttle Control..... **IDLE (pull full out)**
- 2.- Brakes..... **APPLY**

**- ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF**

- 1.- Airspeed..... **70 KIAS - Flaps UP  
65 KIAS - Flaps 10° - FULL**

**- ENGINE FAILURE DURING FLIGHT  
(Restart Procedures)**

- 1.- Airspeed..... **68 KIAS (best glide speed)**
- 2.- FUEL SHUTOFF Valve..... **ON (push full in)**
- 3.- FUEL SELECTOR valve..... **BOTH**
- 4.- FUEL PUMP Switch..... **ON**
- 5.- Mixture Control..... **RICH (if restart has not occurred)**

## FIREs

### - DURING START ON GROUND

1.- **MAGNETOS Switch**.....**START**  
**(continue cranking to start the engine)**

### IF ENGINE STARTS

2.- Power.....1.800 RPM (for a few minutes)  
3.- Engine.....SHUTDOWN (inspect for damage)

### - IF ENGINE FAILS TO START

2.- **Throttle Control**.....**FULL (push full in)**  
3.- **Mixture Control**.....**IDLE CUTOFF (pull full out)**  
4.- **MAGNETOS Switch**.....**START (continue cranking)**  
5.- **FUEL SHUTOFF Valve**.....**OFF (pull full out)**  
6.- **FUEL PUMP Switch**.....**OFF**  
7.- **MAGNETOS Switch**.....**OFF**  
8.- **STBY BATT Switch**.....**OFF**  
9.- **MASTER Switch (ALT and BAT)**.....**OFF**

### - ENGINE FIRE IN FLIGHT

1.- **Mixture Control**.....**IDLE CUTOFF (pull full out)**  
2.- **FUEL SHUTOFF Valve**.....**OFF (pull full out)**  
3.- **FUEL PUMP Switch**.....**OFF**  
4.- **MASTER Switch (ALT and BAT)**.....**OFF**

## FIREs

### - ELECTRICAL FIRE IN FLIGHT

- 1.- STBY BATT Switch.....**OFF**
- 2.- MASTER Switch (ALT and BAT).....**OFF**
- 3.- Cabin Vents.....**CLOSED (to avoid drafts)**
- 4.- CABIN HT and CABIN AIR Control Knobs.....**OFF (push full in)  
(to avoid drafts)**
- 5.- Fire Extinguisher.....**ACTIVATE (if available)**

### - CABIN FIRE

- 1.- STBY BATT Switch.....**OFF**
- 2.- MASTER Switch (ALT and BAT).....**OFF**
- 3.- Cabin Vents.....**CLOSED (to avoid drafts)**
- 4.- CABIN HT and CABIN AIR Control Knobs.....**OFF (push full in)  
(to avoid drafts)**
- 5.- Fire Extinguisher.....**ACTIVATE (if available)**

### - WING FIRE

- 1.- LAND and TAXI Light Switches.....**OFF**
- 2.- NAV Light Switch.....**OFF**
- 3.- STROBE Light Switch.....**OFF**
- 4.- PITOT HEAT Switch .....**OFF**